

MICRON 486PCI MAGNUM

ISA/PCI-Bus System User's Manual

P/N MA1062
Rev. 1.0
5/94



Printed on Recycled Paper






Table of Contents

Chapter 1

Setting Up Your System

Unpacking	1-2
Setup.....	1-3
Maintenance	1-8

Chapter 2

Technical Information

Overview	2-2
System Board Options	2-13
SIMM Modules	2-15

Chapter 3

The BIOS Setup Program

Setup	3-2
Setting the CMOS Main Screen	3-6
Setting the CMOS Extended Screen	3-8

Chapter 4

Common Problems

Introduction	4-2
--------------------	-----

Chapter 5

Mouse User's Guide

Getting Started	5-3
Installing the Hardware	5-5
Installing the Software	5-7
Using Mouse Manager	5-10
Troubleshooting the Mouse	5-22

Appendix A: Contacting Technical Support

Appendix B: Post and Boot Messages

Appendix C: Hard Drive Information

Appendix D: Glossary

Chapter 1

Setting Up Your System

Unpacking	2
First, Check the Packaging	2
Next, Unpack Your System	2
Finally, Check Your Packing List	2
Setup	3
Getting Started	3
What You Need	3
Putting It All Together	3
Running Your System for the First Time	7
Turning Off Your System	7
Maintenance	8
Operating Environment	8
Transporting	8
Cleaning	8
Protection	9
Backup	9

Unpacking

First, Check the Packaging

As soon as the packages containing your new system arrive, carefully inspect them for any signs of damage. In particular, look for wrinkled or bent corners, holes, or other signs of bad handling or abuse. If you notice any damage to the packaging, immediately open the boxes, following the directions below, and inspect the contents for damage. Pay close attention to the components near the area where the packing material was damaged.

Next, Unpack Your System

Caution: If your system arrives in cold weather, do not unpack the computer or the monitor until they have been allowed to warm to room temperature. Immediately exposing them to the warm room may cause condensation to occur, which may damage the units. If condensation does occur, allow the units to completely dry before operating them.

Once you have determined that the packaging has not been damaged, unpack and carefully inspect your system. Take care not to damage the packing material while opening the cardboard box containing the computer and remove the system unit, keyboard, MS-DOS package, and any other accessories that you may have ordered.

Next, carefully unpack the monitor and all accessories from the monitor package while taking care not to damage the packing material.

Once you have unpacked your entire system, inspect all items for damage that may have occurred during shipment. ***For your protection, report any damage to the shipper immediately.***

We highly recommend that you save the packaging in the event that you need to move or ship the system sometime in the future.

Finally, Check Your Packing List

Now that you have everything out of the packages, take the time to check the items against the packing list to be sure you received everything. If you discover that an item is missing, call Micron Computer, Inc. immediately to receive a replacement.

Setup

Getting Started

Before your new system left the factory, the hardware was configured, the display adapter was set to work with your monitor, and the hard disk was partitioned and formatted for DOS. Later DOS was installed, using the standard default settings for your machine. In essence, your computer system is ready to go. All you have to do is plug it in.

What You Need

Grounded power outlet
Phillips-head screwdriver
Power filter/surge protector (recommended)

Putting It All Together

Before you begin, take a moment and review Figure 1-1 or Figure 1-2a and Figure 1-2b to acquaint yourself with the front and back of the system.

Next, check the voltage selector on the rear of the unit. Be sure it is switched for the proper voltage (115V in the United States and Canada).

Place the monitor where your preference dictates, as long as its cable can still reach the video connector at the rear of the computer.

Unpack the power cable for the computer and plug the appropriate end into the power inlet at the back of the system. Insert the other end into a grounded power outlet. We highly recommend that you obtain a protection device (i.e. UPS, power filter, surge suppressor, etc.) for your power line. This provides the utmost protection for your system and data.

NOTE: Please take a moment to ensure that the system is turned OFF before proceeding. Attaching peripherals while the power is on may damage the unit or the peripherals.

Locate the monitor's power cable and plug the appropriate end into the monitor (if not already attached). Insert the other end into the grounded outlet or protection device.

Find the video cable and attach the appropriate end into the monitor (if not already attached) and attach the other end into the video adapter socket (located in one of the expansion slots at the rear of the unit). If the connection is loose on either end, tighten the integrated screws at both ends of the cable for a secure connection. For more information about the setup, use, and maintenance of your video monitor, please refer to the manual that was supplied with it.

Micron 486PCI Magnum User's Guide




Figure 1-1

Chapter 1: Setting Up Your System




Figure 1-2a

Micron 486PCI Magnum User's Guide




Figure 1-2b

Chapter 1: Setting Up Your System

Insert the end of the keyboard cable into the keyboard socket at the rear of the computer system. Take care, for the socket is keyed in such a way that the plug can only be inserted if oriented correctly. ***If it does not plug in easily, do not force it.***

Your system should now be ready to use. You may have other devices or peripherals to install, but it is best to ensure the basic system is operating correctly before adding any options.

Running Your System for the First Time

First, power up the monitor. If you are unsure about how to go about this, please refer to the monitor's manual for more information.

Be sure no floppy disks are in any of the floppy drives. Power up the computer system by firmly pushing the "Power" button on the front panel of the system. The power LED should light up and the fan and hard drive should begin to run.

The system diagnostics should begin at this time. The keyboard will be initialized (indicated by the keyboard LEDs lighting briefly then extinguishing, except for the Num Lock light which will remain on). Next, the screen should initialize and a message indicating what type of video adapter is installed should be displayed.

At this point, the memory will be counted and tested.

Finally, the DOS operating system is booted. For more information about DOS, please refer to the provided DOS manual.

If you experience any problems during the power up sequence, please refer to the Troubleshooting section in Chapter 4 of this manual.

Turning Off Your System

It is recommended that you power down your system in the following order:

Exit all applications you are running and save any changes.

Make sure that ALL disk activity has completely stopped.

The floppy and hard drive indicator lights should be off and the floppy drive motors should be stopped (hard disks continue to spin until the system power has been shut off).

Turn off the computer system, then the monitor.

Maintenance

Operating Environment

Your Micron computer has been manufactured to the highest standards. With proper care, it should provide years of trouble-free service.

To ensure that your system has the longest life possible, it should be placed in an area with good ventilation and low humidity, out of direct sunlight and away from heat sources or lamps. To keep the system from overheating be sure the rear cooling-fan opening is not obstructed. Never expose the system to moisture of any sort, for this could lead to fire or shock hazard. Stay away from areas with high levels of dust, dirt, or smoke.

Transporting

Always shut the system completely off before moving it. Any sudden jar or shock may permanently damage the hard drive. Hard drives are more resistant to shock if they are shut down.

If you are transporting the system over a distance, it is a good idea to completely repackage it in its original packing material. If the original packing is unavailable, pack all components with as much padding as reasonably possible to ensure the units are not exposed to excessive vibration or shock.

Cleaning

If the outside of the system unit becomes dirty through constant use or handling clean it using only a damp, dust-free cloth. Do not use abrasives or solvents as these may mar or scratch the case. Window cleaner and a cloth can be used to clean the monitor, but only if the monitor has been turned OFF first. Never apply the window cleaner directly to the monitor screen. Always spray the cloth first, then wipe down the screen.

Cleaning kits designed to clean floppy drives are available from most computer stores and should be used periodically. If you are operating your system in an environment heavy with smoke or dust, you should occasionally open the unit and WITH GREAT CARE clean the components with a vacuum (special vacuums are available just for this purpose). Be careful to not loosen any of the components.

If liquid is spilled into the keyboard, immediately unplug it, allow the fluid to drain out by tipping the keyboard upside down, and dry the keyboard overnight before using it again.

Protection

Problems with the electrical supply are notorious for causing system failures. To prevent normal electrical problems, such as spikes or surges, a power surge/filter should be installed between the power outlet and ALL of the connected components. If even one component is not connected, the entire system could be at risk.

If a severe storm system enters your area, completely unplug the entire system from all electrical sources, including phone lines. Lightning can travel in on any line and destroy all connected components.

If possible, do not turn the system on and off frequently. This stresses the power supply and may shorten the life of some components. If the system needs to be restarted, use the reset button located at the front of the system unit. However, if the hard drive is active **DO NOT RESET THE SYSTEM** or data loss will most certainly occur. If you do not use the reset button to restart the system, be sure the hard drive has come to a complete stop before reapplying the power.

Backup

Even with today's technology, data loss can occur at any time. We cannot stress enough that you should backup often. There are a large number of backup alternatives available on the open market, from floppy drive backup systems, to tape backup systems, to optical backup systems. Any of these alternatives are highly recommended as long as some method is used. Complete, frequent backups can save years of data from total and irretrievable destruction. If you require additional information about backup systems or options, please contact Micron Computer, Inc.

Chapter 2

Technical Information

Overview	2
Memory	2
486 PCI Features	3
PCI Chip Set	4
System I/O Chip	6
The 486 PCI System Board	7
Configuration	8
System Board Options	13
PCI Local Bus Card	13
Installing a VL-Bus Card	14
SIMM Modules	15
Installing SIMM Modules	15
Removing SIMM Modules	16
Memory Configuration	17

Overview

Micron's 486 PCI system is a high-performance system designed to be the basis for your personal computer or workstation. The system board is based on the PCI Local Bus and the PCI chip set.

PCI stands for Peripheral Component Interconnect and is the newest in Local-Bus technology. Features and benefits of the PCI bus include:

- Higher performance than current VESA Local Bus designs
- Ability to auto-configure (i.e. no jumpers or switches required)
- Superior compatibility

The PCI Bus will deliver better performance due to Intel's PCI chip set. This combination of logic will allow the CPU to transfer data to a device via the PCI controller's buffer. This allows the CPU to move on to other tasks rather than waiting for the transfer to complete.

Systems running multi-tasking software, such as OS/2, Windows NT, or Unix, will benefit in better performance due to the software's ability to work concurrently with the CPU. This will allow the PCI Bus and CPU to operate at the same time, something VL-Bus systems cannot do.

Memory

Micron's 486 PCI system board has four banks of DRAM, which provide 128MB maximum memory using on-board SIMMs. The SIMMs include 1M x 32/36 (1MB) through 8M x 32/36 (32MB).

The system board also has 8K of write-back cache internal to the 486 processor and 256K secondary level write-back cache available.

486 PCI Features

The following features are implemented in the standardized PCI architecture:

Baby AT footprint form factor (13.25" X 8.5").

CPU support from 486SX-25MHz to 486DX4-100MHz

Up to 256K standard on-board cache.

Five ISA slots, two PCI local bus slots, and one ISA/PCI slot.

On-board Super I/O controller (SMC 665).

On-board PCI IDE with mode 3 support

Intel's 82420 PCI set.

On-board peripherals, including two serial ports, one parallel port, one floppy connector, and one IDE Interface.

Phoenix Flash EPROM BIOS.

PCI Chip Set

Micron's 486 PCI system implements Intel's PCI (Peripheral Component Interconnect) chip set. The chip set allows for better integration and higher performance for the CPU.

82424TX Cache/DRAM Controller (CDC).

82423TX Data Path Unit (DPU).

82378IB System I/O (SIO).

Each component performs separate tasks, but all work dependently together. The components work as memory, provide second level cache control, and operate as a bridge between the Host Bus and the PCI Bus. Refer to Figure 2-1 on page 2-5 for a simplified diagram of the PCI chip set.

CDC Chip

The 82424TX CDC coordinates the cache and main memory DRAM control functions. The component also provides address paths, and bus control for transfers amongst the host, main memory and the PCI Bus. The chip's cache controller supports both write-through and write-back cache.

The CDC has a dual-ported architecture. This permits concurrent operations on the PCI Bus and the Host Bus. The dual-port main memory DRAM controller interfaces the DRAM with the Host Bus and the PCI Bus.

The CDC works in tandem with the DPU. Together, they work as a full-function, dual-port data path that connects the main memory and forms a PCI bridge to the host subsystem. The component also controls data flow through the DPU.

DPU Chip

The 82423TX DPU provides a 32-bit data path connection between the Host Bus, main memory, and the PCI Bus. The component also supports byte parity for the Host Bus, main memory, and the PCI Bus.

The CDC also has a dual-ported architecture, which permits concurrent operations between the Host Bus and the PCI Bus. The component provides the address paths and bus controls during bus operations amongst the Host Bus, main memory and PCI Bus.

Diagram of the PCI Chip Set




Figure 2-1. PCI Chip Set

System I/O Chip

The 82378IB System I/O (SIO) chip acts as a bridge between the PCI Bus and the ISA Bus. This multi-faceted component incorporates several functions, including:

- Logic for a PCI interface (master and slave).

- ISA interface (master and slave).

- Enhanced seven-channel DMA controller.

- Data buffers to isolate the PCI Bus from the ISA Bus.

- PCI and ISA arbitration.


- 14-level interrupt controller.

- Three programmable timer/counters.

- Integrated BIOS timer.

- Non-maskable-interrupt (NMI) control logic.

Chapter 2: Technical Information



Micron 486PCI Magnum User's Guide

Configuration

There are jumpers on the 486 PCI system board that have to be set before configuring the system board. Setting the jumpers configures various functions on the system board.

Jumpers relay information to the computer to perform specific functions. Refer to the following tables to set the jumpers.

Jumper	Configuration	Setting
J59	P24T CPU only All other CPUs	Not Installed Installed
J71	486SX All Other CPUs	Pins 2-3 Pins 1-2 & 3-4
J73	Enhanced CPU All other CPUs	Pins 1-2 & 3-4 Pins 2-3
J74	Enhanced CPU All other CPUs	Installed Not installed

Table 2-1. CPU Selection

Jumper	Configuration	Setting
W6	DMA Channel 1 DMA Channel 3	Pins 1-2 Pins 2-3
W7	DMA Channel 1 DMA Channel 3	Pins 1-2 Pins 2-3
W8	Parallel Uses IRQ 5 Parallel Uses IRQ 7	Pins 2-3 Pins 1-2
J76	Parallel in ECP mode Parallel in Non-ECP mode	Installed Not Installed

Table 2-2. Parallel Port Selection

Chapter 2: Technical Information

Jumper	Configuration	Setting
J52	128K 256K	Pins 2-3 Pins 1-2
J58	128K 256K	Not Installed Installed

Table 2-3. Cache Selection

Jumper	Configuration	Setting
W3	DRAM Parity Check Enabled DRAM Parity Check Disabled	Installed Not Installed

Table 2-4. DRAM Parity Selection

Jumper	Configuration	Setting
W10	Flash ROM in normal mode Flash ROM in recovery mode	Pins 2-3 Pins 1-2

Table 2-5. Flash ROM Mode

Micron 486PCI Magnum User's Guide

Jumper	Configuration	Setting
W12	PCI IDE chip enabled PCI IDE chip disabled	Not Installed Installed

Table 2-6. PCI IDE Chip Selection

Jumper	Configuration	Setting
W13	Primary IDE IRQ selects IRQ 14 Primary IDE IRQ selects IRQ 15	Pins 1-2 Pins 2-3
J19	Secondary IDE IRQ selects IRQ 14 Secondary IDE IRQ selects IRQ 15	Pins 1-2 Pins 2-3

Table 2-7. Primary/Secondary IDE Selection

Chapter 2: Technical Information

Jumper	Configuration	Function\Pin Outs
J7	PS/2 mouse connector (may not be present)	
J8	External PC/AT Keyboard connector	
J10	PS/2 keyboard connector (may not be present)	
J11	PC/AT Keyboard connector (may not be present)	
J12 & J19	Power Supply Connector	
J18	COM Port A	COM1
J21	COM Port 2	COM2
J22	Parallel Port	
J38	IDE Connector	
J39	Floppy Connector	
J54	On-Board IDE LED	
J55	Reset Switch	1-Signal; 2-Ground
J56	Speaker Connector	1-Power LED; 2-N/C; 3-Ground; 4-Ground
J57	Power LED/Keylock	1-Power LED; 2-N/C; 3-Ground; 4-KeyBd LCK; 5-Ground
J81	On-Board PCI IDE Connector	

Table 2-8. Peripheral and Case Connections

Micron 486PCI Magnum User's Guide

Switch	Function	Setting
SW 1-1	Not Used	OFF
SW 1-2	Not Used	OFF
SW 1-3	Not Used	OFF
SW 1-4	Flash BIOS programing enalbed Flash BIOS in write protect	ON OFF
SW 1-5	PCI IDE card installed	ON
SW 1-6	DX-25MHz/DX-50MHz/DX2-50MHz/DX4-75 DX-33MHz/DX2-66MHz/DX4-100MHz	ON OFF
SW 1-7	DX-50MHz All other CPUs	OFF ON
SW 1-8	PS/2 mouse not installed On-board PS/2 mouse uses IRQ 12	OFF ON

Table 2-9. Switch Settings

System Board Options

There are options available for the system board to improve and enhance performance. These options include PCI Local Bus card(s) and SIMMs.

Before adding (or removing) any peripherals, make sure there is a clear work space to work on and that you adhere to all anti-static precautions. If problems arise when installing the peripherals, contact Micron's Technical Support (see Appendix A).

PCI Local Bus Card

Micron's PCI Local Bus slot accommodates all PCI- approved Local Bus cards. Refer to Figure 2-3 on page 2-14 and follow the steps below when installing a PCI card.

Power OFF any devices (printer, display, modem, etc.) attached to the computer.

Power OFF the computer system.

Remove the computer's cover.

Locate an unused PCI slot on the system board.

Insert the card with the bottom edge level (Never insert the card at an angle!).

Holding the card at the center of the top edge, gently push straight in. Do not force the card into place (If it does not fit, take it out and try again).

Make sure the card is fully inserted.

Screw the card into place.

Replace the computer's case.

Micron 486PCI Magnum User's Guide




Figure 2-3. Installing a PCI Card

NOTE: When a PCI card is installed into J14, the ISA slot next to it (J6) cannot be used.

SIMM Modules

Micron's 486 PCI system board has four 32/36-bit (72-pin) SIMM sockets on-board. This extra RAM can increase memory from 8MB up to 128MB using the following SIMM sizes:

4MB- organized as 1MB x 32/36

8MB- organized as 2MB x 32/36

16MB- organized as 4MB x 32/36

32MB- organized as 8MB x 32/36

Memory requires at least two SIMM banks to be filled. Start with bank 0, then work your way up. Bank 0 and Bank 1 of the SIMM sockets must always be filled and contain the same size SIMMs. Bank 2 and Bank 3 of the SIMM sockets, if filled, must contain the same size SIMMs.

Installing the SIMM Modules

Step 1: Using both hands, carefully set the SIMM into the socket at a 45 degree angle, tilted towards the ISA slots (refer to Figure 2-1 and Figure 2-4). Do not force it in or damage may result. Note that the SIMM modules are keyed in such a way that they cannot be inserted incorrectly (refer to Figure 2-5). If you are having difficulty placing them into the socket, check to see that you are not attempting to insert them backwards. Do not lock the module into position at this time.

Step 2: Check to make sure the module is centered in the socket, and that the connector pins of the module line up with the socket connector pins.

- A) Be sure the module is centered and connector pins are aligned.
- B) When the module has been locked in place, be sure both tabs (at the rear of the module) are locked properly.

Step 3: Using both hands and applying equal pressure on each end of the module, lock the module into the socket by pushing forward. Make sure both locking tabs have seated properly. The module should now be standing upright in the socket.

WARNING: Failure to observe proper insertion guidelines may result in damage to the SIMM and/or the socket.




Figure 2-4




Figure 2-5

Removing SIMM Modules

Removing the SIMM modules is simply the reverse of the above procedure with the following differences: Using the thumbs of both hands, gently pry the locking tabs apart so that they no longer hold the module in the socket. While holding the tabs apart, gently pull the module backward to clear the tabs (this should put the module at an angle to the socket). Carefully remove the loose module from the socket.

Memory Configuration

Table 2-11 lists the possible memory size configurations. The BIOS will automatically detect the amount of memory installed.

Memory Size	Bank 0	Bank 1	Bank 2	Bank 3
8MB	4M	4M		
16MB	4M	4M	4M	4M
16MB	8M	8M		
24MB	4M	4M	8M	8M
24MB	8M	8M	4M	4M
32MB	8M	8M	8M	8M
32MB	16M	16M		
40MB	4M	4M	16M	16M
40MB	16M	16M	4M	4M
48MB	8M	8M	16M	16M
48MB	16M	16M	8M	8M
64MB	16M	16M	16M	16M
64MB	32M	32M		
72M	4M	4M	32M	32M
72M	32M	32M	4M	4M
80M	8M	8M	32M	32M
80M	32M	32M	8M	8M
96M	16M	16M	32M	32M
96M	32M	32M	16M	16M
128M	32M	32M	32M	32M

Table 2-10. Memory Configuration

Chapter 3

The BIOS Setup Program

SETUP 2

 BIOS Setup 2

 When Setup Should be Run 2

 How to Run the Setup Program 3

 Running the Setup Procedure 4

 PCI Device Configuration 7

 Setting the CMOS Extended Screen 8

 Exiting/Saving the CMOS Selections 9

SETUP

BIOS Setup

Every AT-compatible computer has a battery supported CMOS memory location that stores information about the system and peripheral configuration. Because of the attached battery, the CMOS is constantly provided with power, even when the computer has been turned off.

During the boot sequence, a special software application called the BIOS (Basic Input Output System), which is located in read-only (ROM) memory on the system board, reads the information contained in the CMOS and configures the CPU and other peripheral devices. If the CMOS information is incorrect, the system may not operate correctly until accurate information is stored in the CMOS. The Setup Program has been built into the system to provide the means for changing the CMOS.

When Setup Should be Run

Although the Micron 486 PCI arrives fully configured, the system may need to be adjusted to fit your needs.

Whenever peripherals are added or removed from the system (for example, if you add a hard disk or more memory), you must run Setup to inform the system about the new configuration.

If the CMOS has lost the information contained within it, the system may not operate properly unless Setup is used to restore the system configuration.

Chapter 3: The BIOS Setup Program

How to Run the Setup Program

If at any time you want to run the Setup Program after your system has been configured, simply press the <CTRL>, <ALT>, and <S> keys at the same time. The screen shown in Figure 3-1 should appear.

Phoenix SETUP Utility (Version 1.00) 00
(C) Phoenix Technologies Ltd. 1985, 1993 All Rights Reserved

****Standard System Parameters**** Page 1 of 3

System Time: 20:59:59
System Date: Wed May 22, 1991

Diskette A:	5.25 Inch, 1.2 MB						
Diskette B:	Not Installed	Size	Hd	Pre	LZ	Sec	Cyl
Hard Disk 1:	Auto Config	234	13	0	0	51	723
Hard Disk 2:	Not Installed						
Hard Disk 3:	Not Installed						
Hard Disk 4:	Not Installed						
Base Memory:	640 KB						
Extended Memory:	3072 KB						
Video Card:	VGA/EGA						
Keyboard:	Installed						

Numlock on all boot: Yes

Esc	F1	F2	F4	F5	PgUp/PgDn
Menu	Help	Sys Info	Field	Value	

Figure 3-1

Micron 486PCI Magnum User's Guide

Running the Setup Procedure

The 486 PCI system board has three CMOS configuration screens: the main screen (Figure 3-1), the PCI Device Configuration (Figure 3-2), and the extended screen (Figure 3-3).

To toggle between the screens, press the PgUp/PgDn keys.

Phoenix SETUP Utility (Version 1.00) 00	
(C) Phoenix Technologies Ltd. 1985, 1993 All Rights Reserved	
PCI Device Configuration Page 2 of 3	
Device Select	: Slot 0
Enable Device	: Disabled
Bus Master	: Disabled
Device IRQ Line	: None

Esc	F1	F2	←	→	+/-	PgUp/PgDn
Menu	Help	Sys Info	Field	Value		

Figure 3-2

Now, configure the computer's parameters to match your specific requirements. See the following pages for the procedures on how to set the computer's parameters.

Before running the computer, there are certain parameters on the CMOS configuration screens that have to be set so that the computer can operate properly. To return to the CMOS configuration screens at any time to change or view any of these parameters, press <CTRL>, <ALT>, and <S> simultaneously.

First, set the parameters on the CMOS main screen, then press the PgUp/PgDn key to set the parameters on the other screens.

NOTE: Some of the parameters are already set and do not need to be changed. Only change the settings if necessary.

Chapter 3: The BIOS Setup Program

Phoenix SETUP Utility (Version 1.00) 00			
(C) Phoenix Technologies Ltd. 1985, 1993 All Rights Reserved			
		Page 3 of 3	
Serial Port A:	COM1(3F8h)	Boot Sequence:	A:First
Serial Port B:	COM2 (2F8h)	Swap Floppies:	Normal
Parallel Port:	LPT1 (378h)	Cache State:	Cache Enabled
Parallel Port Mode:	AT	Cache Mode:	Write back
Onboard PCI IDE:	Enabled	Video BIOS:	Shadowing Enabled
Master Speed:	Normal	Energy Saving Timer:	Disabled
Slave Speed:	Normal		
Onboard ISA IDE:			
Onboard Floppy:	Enabled		
Esc	F1	F2	+/- PgUp/PgDn
Menu	Help	Sys Info	Field Value

Figure 3-3

Micron 486PCI Magnum User's Guide

SYSTEM TIME AND DATE

To set the time, use the - key to decrease the number; use the + key to increase the number. To move the prompt forward, use the right arrow key; to move the prompt backward, use the left arrow key.

Follow the same procedure for the date.

DISKETTE A OR B

This allows you to configure a diskette drive added or removed from your computer. Use the +/- keys to toggle between the options.

HARD DISK 1 OR 2

This parameter allows you to configure a hard disk to the primary PCI IDE connector or an off-board controller. Use the +/- keys to toggle between the options. See Appendix C for a complete listing of the available hard disk drives.

To install most SCSI hard drives, select NOT INSTALLED. To install an ESDI or RLL hard drive, select TYPE 1. To manually configure the hard drive, select USER CONFIG. Press the right directional key and type in the appropriate parameters. To automatically configure an IDE hard drive, select AUTO CONFIG. A drive that has the capability to be Auto-Configured will report its parameters to the BIOS.

HARD DISK 3 OR 4

This parameter allows you to configure a hard disk to the secondary ISA IDE connector. The settings are the same as the parameters for HARD DISK 1 OR 2.

For a complete listing of all the possible hard drive types, see Appendix C.

BASE MEMORY AND EXTENDED MEMORY

Both of these memory settings are automatically configured. Use the down arrow key to move to the next selection.

VIDEO CARD

This sets the type of monitor required for your computer. The Display peripheral will support VGA/EGA, Monochrome (MONO), or no monitor at all. Use the +/- keys to toggle between the options.

KEYBOARD

The Keyboard function is set to INSTALLED for keyboard error reporting. To turn off keyboard error reporting, use the left/right arrow keys to toggle the keyboard NOT INSTALLED.

Chapter 3: The BIOS Setup Program

NUMLOCK AT BOOT

This sets the NUMLOCK on the keyboard to the ON position after the computer is Booted up. NUMLOCK keeps the number keys as numbers. You can then disable the NUMLOCK by pressing the NUMLOCK key.

PCI DEVICE CONFIGURATION

Now press the PgUp/PgDn key to set the parameters on the PCI Device Configuration (refer to Figure 3-2). You can toggle between all three screens using the PgUp or PgDn key.

DEVICE SELECT

This option is used to select the PCI device in Slot 0, 1, and 2. This features enables features such as Latency Timer and Bus Master.

ENABLE DEVICE

This option enables the PCI peripheral installed in the PCI slot (s). Use the +/- keys to toggle between the options.

ENABLE MASTER

This option enables the bus-master capability of the PCI Bus master peripheral when it is set to ENABLED. Use the +/- keys to toggle between the options.

DEVICE IRQ LINE

This option selects the IRQs (5, 11, and 15) for the PCI slots. The IRQs will be the same for all slots (0 through 2), since the IRQs are shared. IRQ 14 is used by the On-Board IDE controller, so it should not be used. Use the +/- keys to toggle between the options.

Setting the CMOS Extended Screen

Now press the PgUp/PgDn key to set the parameters on the CMOS extended screen (refer to Figure 6-4).

SERIAL PORT 1

The Serial Port 1 can be selected as COM1. Be sure that this setting does not conflict with any add-on peripherals. The Serial Port 1 can also be set to DISABLED if the On-Board port is not used.

SERIAL PORT 2

The Serial Port 2 can be selected as COM2. Be sure that this setting does not conflict with any add-on peripherals. The Serial Port 2 can also be set to DISABLED if the On-Board port is not used.

PARALLEL PORT

The Parallel Port selection can be selected as LPT1. Be sure that this setting does not conflict with any add-on peripherals. The Parallel Port can also be set to DISABLED, if the On-Board port is not used.

ON-BOARD PCI IDE

This selection allows you to disable or enable the On-Board PCI IDE. Use the +/- keys to toggle between the options.

MASTER SPEED

This option selects the modes supported by the PCI IDE controller and identifies the drive connected as the master drive on the primary PCI IDE connector. The selections include ENHANCED, NORMAL (default), or SLOW. Select ENHANCED for higher performance drives that support Mode 3 IDE.

SLAVE SPEED

This option selects the modes supported by the PCI IDE controller and identifies the drive connected as the slave drive on the primary PCI IDE connector. The selections include ENHANCED, NORMAL (default), or SLOW. The modes supported are the same as the Master Speed.

ON-BOARD ISA IDE

This selection allows you to disable or enable the ISA IDE connector on the system board. This option supports standard PIO mode only and is supported by the SMC 665 Super I/O chip. The options include ENABLE and DISABLE (default).

Chapter 3: The BIOS Setup Program

ON-BOARD FLOPPY

This peripheral allows you to disable or enable the On-Board floppy controller. Use the +/- keys to toggle between the options.

BOOT SEQUENCE

This peripheral allows you to select the device to boot from. If you select C:FIRST, the system will boot to "C" without checking the "A" drive.

SWAP FLOPPIES

This selection allows you to change Floppy A to Floppy B and vice-versa by setting the parameter to SWAPPED. This will allow you to boot from the B drive if it is necessary.

CACHE STATE

This selection allows you to enable the internal (80486) cache, or both the internal and external cache. For optimum performance, select BOTH CACHES ENABLED.

CACHE MODE

This selection allows you to select the type of secondary cache installed on board. The system can utilize the WRITE-THROUGH or WRITE-BACK mode. When adding additional cache, make sure the jumpers are set correctly.

VIDEO BIOS

Choosing SHADOWING ENABLED copies the system's video BIOS into RAM for faster execution. Some video cards cannot be shadowed, in which case this selection must be set to SHADOWING DISABLED. Use the +/- key to toggle between the options.

ENERGY SAVING TIMER

This selection allows the system to conserve energy by providing a "sleep" mode. When there is no I/O activity the system will spin-down the IDE drive and stop the CPU clock. Time selected options include 1 min, 15 min, 30 min, 45 min, 60 min, 75 min, 90 min, 105 min, and 120 min.

Exiting/Saving the CMOS Selections

Press the <ESC> key to reach the exit pop-up menu. Now select F4 to save and initialize the new Setup.

C

C

C

Chapter 4

Common Problems

Introduction 2
 Problems During Boot 2
 Hard Disk Problems 3
 System Problems 5

Introduction

Occasionally while setting up and configuring a computer system, an error might occur or an important element may be forgotten. This section gives information regarding the most frequently encountered problems as well as many quick and simple solutions. Refer also to Appendix B Post and Boot Messages. If you continue to experience problems and this section fails to alleviate them, please feel free to contact Micron technical support (see Appendix A: Contacting Technical Support).

Problems During Boot

Problem

When the power switch is turned on, the system does not power up (i.e. the exhaust fan does not run, the power indicator light is not illuminated, the hard disk does not begin to spin, etc.).

Possible Cause

- The power cable is unplugged or is bad.
- Voltage switch is improperly set.
- No power at outlet.
- Bad power supply.

Solution

- Check to ensure the power cable is plugged in correctly and firmly. Try a second power cable, if available, or test the cable for continuity. Replace original cable if it is found to be bad.
- Check the red voltage switch (located at the rear of the unit near the fan) and ensure that it is set for the proper voltage (115V in the U.S. and Canada).
- Check the outlet with another appliance (e.g. a lamp)

Chapter 4: Common Problems

Problem

When the power switch is turned on, the system has power (i.e. the exhaust fan runs, the power indicator light is illuminated, the hard disk begins to spin, etc.), but the system appears dead. Generally the keyboard LEDs will stay on.

Possible Cause

- The monitor may not be turned on.
- A peripheral card may not be seated correctly on the system board.
- A peripheral card may be defective.
- A floppy drive may be defective.

Solution

- Check the monitor to ensure that the power is on. If a problem is suspected with the monitor, please refer to the manual that was provided with it.
- Carefully open the system unit. Press down firmly on all peripheral in the expansion slots.
- With the system power shut off, remove one peripheral card, power up the system, and wait a few moments to see if the keyboard light turn off. If they don't, repeat the above steps with the next peripheral card until all have been removed. After this has been completed, contact Micron Technical Support for further assistance.
- With the system power shut off, completely disconnect one of the floppy drives and power up the system. If the keyboard lights do not turn off after a few moments, repeat the above procedure until all drives are disconnected. After this has been completed, contact Micron Technical Support for further assistance.
- Contact Micron technical support if none of the above procedures are effective.

Hard Disk Problems

Problem

System has to be booted from a floppy disk. Hard drive is either unrecognized or unreadable.

Possible Cause

- The connections between the drive and the controller may be bad or loose.
- The hard drive's root directory or file allocation table may be corrupted. Or the controller or hard drive may be defective.

Solution

- Check that the hard drive and controller are connected properly.

Micron 486PCI Magnum User's Guide

Solution (cont)

- If hard drive recovery software is available, attempt to repair the damage with it, otherwise the only other solution is to attempt to do a high-level (DOS) format on the drive. **Do not attempt to low-level format the drive!** If the drive cannot be formatted, either it or the controller may be defective. Contact Micron technical support.

Problem

System has to be booted from a floppy disk. Hard disk is completely functional, but cannot be booted from by the system.

Possible Cause

- The hard drive's boot sector may have become corrupted.

Solution

- If hard drive recovery software is available, attempt to repair the damaged boot sector with it, otherwise the only other solution is to attempt to do a high-level (DOS) format on the drive and transfer the DOS system to the boot sector. **Do not attempt to low-level format the drive!** Do a complete file-by-file backup of your data before formatting your drive.

Problem

Read/write, sector, data, or seek errors occur when attempting to access files on the hard drive.

Possible Cause

- The format may be fading.
- The hard drive may be developing media errors.
- The file allocation table may be corrupted.

Solution

- Using a file-by-file backup method, backup as much data as you can, then reformat the drive. Afterwards, if the format was successful, use a disk diagnostic software application to test the media of the drive (make sure the application locks out any errors it finds to make them inaccessible from DOS). Finally, restore your files from the backup tape or diskettes.

System Problems

Problem

After installing a new peripheral card, an unrelated part of the system suddenly stops working.

Possible Cause

- The new card may be attempting to use some of the same system resources, such as address space, I/O ports, interrupt lines, etc., and may be conflicting with the failing part of the system.

Solution

- Most peripheral cards have jumpers or switches that configure the card to use different I/O ports, interrupt lines, or address regions. Please refer to the documentation that was provided with the new card and try to change the settings to eliminate the conflict.

Problem

A large number of bad sectors are encountered when attempting to format diskettes.

Possible Cause

- Typically, Micron computers are provided with 1.2MB 5.25" and 1.44MB 3.5" floppy drives. An attempt may have been made to format a low-density disk in one of the Micron high-density floppy drives.

Solution

- Please refer to the DOS manual for more information about how to format low-density diskettes in high-density floppy drives.

C

C

C

Chapter 5

Mouse User's Guide

Getting Started	5-3
Checklist of Essentials	5-3
The README.TXT File	5-4
Radio Interference Information	5-4
Installing the Hardware	5-5
Installing a Serial Mouse	5-5
Installing a Mouse with Mouse Port (PS/2) Connector	5-6
Installing the Software	5-7
Running the Setup Program	5-7
Files on the Setup Disk	5-8
Using Mouse Manager	5-10
Running Mouse Manager for Windows	5-11
Mouse Manager Extra Points	5-14
Orientation	5-15
Running Mouse Manager for MS-DOS	5-19
Troubleshooting the Mouse	5-22
Troubleshooting Table	5-22
Cleaning Your Mouse	5-25
Mouse Settings	5-26
Product Support	5-27
United States Radio and TV Interference Regulations	5-28

Micron 486PCI Magnum User's Guide

Information in this document is subject to change without notice. Companies, names, and data used in examples herein are fictitious unless otherwise noted. No part of this document may be reproduced or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Microsoft Corporation.

© 1984-1993 Microsoft Corporation. All rights reserved.

Microsoft, MS, MS-DOS, and InPort are registered trademarks and Windows is a trademark of Microsoft Corporation in the United States of America and other countries.

IBM, PC/AT, Personal System/2, and PS/2 are registered trademarks and PC/XT is a trademark of International Business Machines Corporation.
Document No. HA 51523-0593

Getting Started

This chapter contains information to help you get started with your mouse.

Checklist of Essentials

You need the following software and hardware to use your mouse:

MS-DOS® version 2.0 or higher

A personal computer and display

The Microsoft Mouse is designed for use with personal computers that are 100-percent compatible with MS-DOS.

Make sure the following items are included in your Microsoft Mouse package:

A Mouse

The Setup disk

This *Mouse User's Guide*

The README.TXT File

The Setup disk with your mouse includes a file named README.TXT. This file contains information that became available after this book was printed. After you install the mouse software, you can access the README.TXT file from the mouse program group in Microsoft® Windows™. You can also read the file before you run Setup.

To read the README.TXT file from MS-DOS

1. Insert the Setup disk into the disk drive.
2. At the command prompt, specify the disk drive and type **readme**.
For example, type **a:readme** if you're using drive A.

To print README.TXT from MS-DOS

1. Make sure your printer is ready to receive information from the computer.
2. At the command prompt, type
copy a:readme.txt lptn (or **comn**, if you have a serial printer)
where **n** is 1 or 2, depending on your printer.

Radio Interference Information

This device complies with Part 15 of the U.S. Federal Communications Commission (FCC) Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

For more information, see "United States Radio and TV Interference Regulations" at the end of this section.


Installing the Hardware

This chapter explains how to connect the mouse hardware. There are two versions of the mouse to accommodate different systems: serial and mouse port (PS/2).

Installing a Serial Mouse

If you have a 9-pin serial mouse (see connector below), connect the mouse to your computer by following the instructions below. Then skip the rest of this chapter and turn to "Installing the Software."

NOTE: Always turn the computer OFF before connecting or disconnecting your mouse.




To connect the 9-pin serial mouse to your computer:

1. Turn your computer off.
2. Locate an available 9-pin serial port on the back of your computer (this port may be oriented either vertically or horizontally).
3. Insert the serial connector into the serial port and tighten the screws.
4. Start your computer.

Installing a Mouse with Mouse Port (PS/2) Connector

If you have a mouse with a round mouse port connector (also known as a PS/2 connector), connect the mouse to your computer by following the instructions below. Then skip the rest of this chapter and turn to "Installing the Software."

NOTE: Always turn the computer OFF before connecting or disconnecting your mouse.



To connect the mouse port to your computer:

1. Turn the computer off.
2. Locate an available 6-pin round port on your computer.
3. Insert the mouse connector into the round mouse port.

NOTE: Some round ports may look similar to the mouse port, but they may be incompatible with the connector on the mouse-port cable. If you cannot connect the mouse easily, do not force it. Locate the compatible round port or contact your computer dealer or hardware manufacturer for assistance.

4. Start your computer.

Installing the Software

This chapter explains how to set up the mouse software. The Setup disk that came with your mouse includes the software you need to set up and use the mouse.

Running the Setup Program

You can run the Setup program from either MS-DOS or Microsoft Windows (version 3.0 or higher). Once you start Setup, follow the instructions provided on the screen. Help is available in MS-DOS through windows at the bottom of the screen and in Microsoft Windows by pressing F1 or clicking the Help button.

If you would like the easiest, most convenient form of Setup, or if you are not comfortable with choosing which files to load, accept all the defaults and Setup will install the mouse software for MS-DOS and Microsoft Windows for you. If you have limited disk space, you can use the Custom option to have Setup install only specific files.

NOTE: Most of the files on the Setup disk are in a compressed format. The Setup program decompresses these files when it copies them to your disk. Compressed files are denoted with a dollar sign (\$) in the filename extension. For example, MOUSE.EX\$ is the compressed form of MOUSE.EXE.

Micron 486PCI Magnum User's Guide

To run Setup

1. Install the mouse hardware before you run Setup. See "Installing the Hardware" earlier in this section.
2. Start your computer.
3. Insert the Setup disk into the disk drive.
4. If you are running Setup from MS-DOS, skip to step 5.
If you have Microsoft Windows 3.0 or higher, start Windows. From the File menu in Program Manager, choose Run.
5. Specify the disk drive, and type **setup**. For example, type **a:setup** if you are using drive A.

In Windows 3.1 or higher, Setup integrates Mouse Manager into the Windows Control Panel. Setup also installs a mouse program group in Windows Program Manager. This group includes icons for a README file and Mouse Manager. You can move or copy the mouse program items into other program groups in Program Manager. For more information on program items and groups, see the *Microsoft Windows User's Guide*.

Files on the Setup Disk

If you choose a complete set up of the mouse software for Microsoft Windows and MS-DOS, Setup copies the following files to your system:

Filename	Description
ERGODEMO.DLL	Meet the Mouse demonstration
MOUSE.DRV	Mouse driver for Windows
MOUSE.EXE	Mouse driver for MS-DOS
MOUSE.INI	Mouse initialization file
MOUSEMGR.DLL	Library for Mouse Manager
MOUSEMGR.EXE	Mouse Manager for Windows and MS-DOS
MOUSEMGR.HLP	Help for Mouse Manager
POINTER.DLL	Mouse Manager features
POINTER.EXE	Executable file for POINTER.DLL
README.EXE	README viewer
README.TXT	Notes for this software version

The Mouse Drivers

The file that lets your mouse work with your computer is the mouse driver. The mouse driver for MS-DOS is called MOUSE.EXE. The mouse driver for Microsoft Windows is called MOUSE.DRV.

README file

The README file (README.TXT) contains information not available when this section was printed.

Meet The Mouse

Meet The Mouse for Microsoft Windows (ERGODEMO.DLL) is a short, animated demonstration that details the ergonomic and software features of the mouse. After Setup copies the files to your disk, you can run Meet The Mouse. Click the Meet The Mouse button from the final screen of Setup to start the demonstration. You can also run Meet The Mouse any time from Mouse Manager by clicking the Meet The Mouse button. To save disk space, you can delete this demonstration any time by deleting the ERGODEMO.DLL file from the directory that contains your mouse software.

Mouse Manager

Mouse Manager in MS-DOS and Microsoft Windows (MOUSEMGR.EXE) lets you customize the way the pointer responds as you move your mouse. It offers you a variety of features that turn your mouse into a powerful computing tool.

After Setup from MS-DOS copies the files to your disk, it asks if you would like to run Mouse Manager.

When installation from Windows is complete, Setup restarts Windows and automatically opens Mouse Manager to the Orientation screen so that you can begin customizing your software immediately. It is important to set Orientation immediately since you can hold the mouse in a variety of positions and you need to tell the software which way is up for your mouse. Then reset Orientation periodically because the way you hold the mouse may change over time.

After you complete the Setup program, you are ready to use the mouse with your applications. See "Using the Mouse" for details on using the mouse and "Using Mouse Manager" for information on Mouse Manager.


If you encounter problems while running Setup, see "Troubleshooting the Mouse" later in this section.

Using Mouse Manager

This chapter describes the various Mouse Manager features. Mouse Manager helps turn your pointing device into a powerful computing tool. Both the Microsoft Windows and MS-DOS versions of Mouse Manager let you adjust several mouse options.

NOTE: If you do not have Mouse Manager (shown in this chapter), your computer manufacturer did not install the mouse software that comes with this mouse.

Running Mouse Manager for Windows



When Setup installs for Windows, Mouse Manager replaces the standard mouse options in the Control Panel that comes with Windows 3.1. For all versions of Windows 3.X, a new program group is created that includes Mouse Manager. Mouse Manager includes extensive Help, accessible by pressing F1 or by choosing the Help button.

To run Mouse Manager for Microsoft Windows

1. In Windows 3.0, open the Mouse group.
In Windows 3.1, open the Windows Control Panel or Mouse Group.
2. Double-click the mouse icon.

Each feature in Mouse Manager is described on the following pages.

Micron 486PCI Magnum User's Guide



Size

Use this feature to adjust the pointer size. You can choose a small, medium or large pointer. Choosing a larger size may dramatically improve pointer visibility on liquid crystal display (LCD) screens. Select the desired pointer size on the screen.



Pointer Growth

Use this feature to enable Pointer Growth if you choose a medium or large pointer. This feature makes the pointer grow to the selected size depending on the Trigger Speed; then the pointer shrinks back to its smaller size depending on the Duration. Trigger Speed is a speed limit, and Duration is a time period. When you move the pointer faster than the Trigger Speed, the pointer switches to the larger size. After the mouse stops moving, the pointer waits the Duration, then switches to the smaller size. Duration can vary from zero to 10 seconds.

NOTE: Application-specific pointers in Windows grow but do not shrink back to the smaller size.



Color

Use this feature to choose the color of the pointer. Choosing a different color may dramatically improve pointer visibility, especially on LCD screens. You can choose a normal, reverse or transparent pointer. Select the desired pointer color on the screen.



Mouse Trails

Use this feature to give your pointer a comet-like effect that helps improve pointer visibility on your screen. When you turn on the Mouse Trails Enabled box, you can also adjust the length of the mouse trail.

NOTE: This feature is supported for Microsoft video drivers that come with Windows 3.1 (EGA, VGA, and Super VGA) and drivers that are 100-percent compatible with Windows 3.1 video drivers.




Meet The Mouse

Run Meet The Mouse to see a short, animated demonstration that details the ergonomic and software features of the mouse. You can delete this demonstration to save disk space by deleting the ERGODEMO.DLL file from the directory that contains your mouse software.

NOTE: This feature is supported for VGA or higher-resolution displays.

Mouse Manager Extra Points




The Extra Points features of Mouse Manager are powerful tools that let you manipulate the pointer on the screen. To enable a feature in Extra Points, turn on the box next to the feature.

Two of the features, Magnify and Locate, need a combination of a keyboard key and a mouse button for operation. When you enable these features in Mouse Manager, a list box appears and gives you a list of mouse and key combinations. Select the combination of your choice. When you want to activate Magnify or Locate, press the key and click the mouse button you selected. If you do not remember, you will find your choice listed below the feature in Mouse Manager.

NOTE: Press the key first and hold it down while clicking the mouse button to activate Magnify and Locate.

Orientation




Click the Orientation button on the first Mouse Manager window to open the Orientation screen. The Orientation screen includes the Button and Orientation Selection features.



Button Selection

Use this feature to specify the buttons you want to use as your primary and secondary buttons. The primary mouse button is most commonly the left button on the mouse, but you can customize your mouse buttons so that the primary button is the right button. This is so that you can use the mouse with ease in either hand. To run Button Selection, click Set Buttons and follow the instructions on the screen.

NOTE: Primary and secondary buttons are referred to as left and right buttons in some documentation.




Orientation

Use this feature to set the direction for the pointer to travel on the screen when you move the mouse. Individual mouse users hold and move the mouse differently, and Orientation lets each user customize the software to arrive at the most comfortable alignment. This is also helpful if you vary your hand positions. To run Orientation, click the Set Orientation button and follow the instructions on the screen.

Remember, you are setting the direction in which the ball of your mouse is traveling. You can align your mouse in a variety of positions, then use Orientation to tell the software which way is up for the ball of your mouse. This feature lets you occasionally change the way you hold the mouse-you will find this to be a comfortable work habit.

Sensitivity



Click the Sensitivity button on the first Mouse Manager window to open the Sensitivity screen. Sensitivity includes Overall Pointer Speed, Acceleration and Double-Click Speed.



Pointer Speed

Use these features to control how fast or slowly the pointer moves as you move your mouse. Depending on the applications you use, there are times when you may want fast pointer movement and other times when you may want very slow, fine pointer movement.

Micron 486PCI Magnum User's Guide

Overall Pointer Speed is the ratio of actual mouse movement to pointer movement. You can adjust Overall Pointer Speed using slider bars to set axes independently. That is, the sensitivity for the horizontal (left/right) axis can be different from the sensitivity for the vertical (up/down) axis. You can also change the sensitivity settings for both axes simultaneously by clicking the large arrows on either side.

Acceleration varies sensitivity with changes in the speed of the mouse. For example, when you use an accelerated mouse profile (Low, Medium, or High), and you move the mouse quickly—even over a very small distance—the pointer moves farther across the screen than when you move the mouse slowly. A small, fast mouse movement can move the pointer completely across your screen, while a large, slow movement may move the pointer only an inch or two. Try each of the four selections to see which works best with your application.



Double-Click Speed

Use this feature to set the speed with which the software recognizes a double-click. Double-clicking means pointing to an object on the screen and quickly clicking a mouse button twice.

Double-click the Test box to see how fast your double-click setting is recognized. The clapper board opens or shuts when it recognizes a double-click.

Command Buttons


OK saves the settings you have made in the current session of Mouse Manager and closes the active screen. Mouse Manager writes the configuration to the MOUSE.INI file and these settings are saved until the next time you change them.

Cancel undoes any of the changes you have made to the pointer during the current session in Mouse Manager, then closes the screen in which you are currently working.

Reset returns the pointer to its default Microsoft Windows pointer settings. This button only applies to the first Mouse Manager window.

Help provides extensive help on the mouse and its software. See "Viewing Technical Notes" in Help for additional information about the mouse.

Running Mouse Manager for MS-DOS



The MS-DOS version of Mouse Manager lets you adjust several mouse options for MS-DOS based applications. Use the following procedure to run Mouse Manager for MS-DOS.

If the mouse is not in your AUTOEXEC.BAT path, first change to the directory that contains Mouse Manager before you run the program.

Micron 486PCI Magnum User's Guide

To run Mouse Manager for MS-DOS

1. Make sure your mouse is connected and that the mouse driver is loaded.
2. At the command prompt, type:

mousemgr

Mouse Manager is displayed. An error message is displayed if the MS-DOS mouse driver is not properly loaded.

Chapter 5: Mouse User's Guide

You can set the following features for applications available in MS-DOS:

Acceleration

When you select a different acceleration profile, you change the ratio between the distance the pointer moves on your screen and the speed of mouse movement. These profiles are listed by name in Mouse Manager. Acceleration profiles cause the pointer to move greater or lesser distances across the screen depending upon how quickly you move the mouse.

Help

Help is available for each option in Mouse Manager.

Buttons

Mouse Manager lets you choose the buttons that you want to use for primary and secondary buttons. Some documentation refers to these buttons as right and left buttons.

Orientation

Orientation sets the direction for the pointer to travel on the screen when you move the mouse. Individual mouse users hold and move the mouse differently, and Orientation lets each user customize the software to arrive at the most comfortable alignment.

Pointer

The Pointer options let you adjust the size and color of the pointer. If you increase the size of the pointer, you can also adjust the threshold and delay of pointer growth. (These features are called Trigger Speed and Duration in the Windows version of Mouse Manager.) The Growth feature makes the pointer grow to a larger size depending on the threshold setting (a speed limit); then the pointer shrinks back to its smaller size depending on the delay setting (a time period).

Sensitivity

Mouse sensitivity is the ratio of actual mouse movement to pointer movement. The sensitivity for the horizontal (left/right) axis can be different from the sensitivity for the vertical (up/down) axis. You can also change the sensitivity settings for both axes simultaneously by clicking the large arrows at either end.

Troubleshooting the Mouse

This chapter provides tips and strategies for problems you may encounter with the mouse either during installation or normal use. Details on cleaning your mouse are also included here.

Troubleshooting Table

Use the following guide if you encounter problems with your mouse.

Problem

General failures during Setup

Action

Setup may not work properly if you have used the MS-DOS append command. If this command is in effect, remove it before running Setup by typing append; at the MS-DOS command prompt (include the semicolon). If Setup fails from Windows, exit Windows and try running Setup in MS-DOS. Conversely, if Setup fails from MS-DOS, try running it in Windows.

Chapter 5: Mouse User's Guide

Problem

The message "Microsoft Mouse not found. Try another 9- or 25- pin serial port and/or check for interrupt conflicts with other peripherals" appears after running Setup.

Action

Try typing mouse/F at the prompt in the directory that contains your mouse software in MS-DOS for a list of all the mouse devices.

If your mouse is attached to a serial port, make sure that your port is configured correctly. Your port should conform to IBM standard RS-232C. (Serial port COM1 should use interrupt IRQ4, and COM2 should use IRQ3. Those interrupts should not be shared by other devices.)

If you have an internal modem or a netcard on IRQ3 or IRQ4, you may have a conflict. Switch your mouse to a different serial port or reconfigure your serial port so that it does not conflict with the mouse port (see the user's guide for your computer).

If, after checking the mouse installation and restarting your computer, you still receive the error message, you may want to try installing the mouse on another system to determine whether the problem is with the mouse or the system. If you still have problems, call Micron Computer, Inc.

Problem

Erratic mouse movement.

Action

Clean the mouse. See "Cleaning Your Mouse" in this chapter.

If the mouse movement is still erratic after you have cleaned it, remove the ball and move the rollers with your finger. Watch to see if the pointer is erratic in the horizontal or vertical direction and note that. Then try this on a different machine. If you obtain the same results, the problem is the mouse. Call Micron Computer, Inc.

If the movement is erratic in both the horizontal and vertical directions, try a different mouse on the same machine to determine if the problem is software or hardware related. Then call Micron Computer, Inc.

If you are using a serial to PS/2 adapter, remove the adapter and try using your mouse on the serial port.

Micron 486PCI Magnum User's Guide

Problem

The message "Microsoft Mouse not found. Try another 9- or 25- pin serial port and/or check for interrupt conflicts with other peripherals" appears after you have been using your mouse for some time.

Action

If you have recently installed another device into your computer, remove it. If the problem goes away, you may have an interrupt conflict. If your mouse is connected to the COM1 interface, use COM2 or COM4 for the other device. If your mouse is connected to COM2, use COM1 or COM3 for the other device.

Try typing mouse/F at the prompt in the directory that contains your mouse software in MS-DOS for a list of all the mouse devices.

Problem

General mouse problems

Action

If you change the configuration of your system after you have installed the mouse software, you may need to run Setup again to set up the mouse software for the new configuration.

Try typing mouse/? at the prompt in the directory that contains your mouse software for help about the MS-DOS mouse driver.

Cleaning Your Mouse

If you notice that the pointer does not move smoothly or that the mouse does not move freely, you should clean your mouse.

To clean your mouse:

1. Turn your computer off.
2. Turn your mouse upside down and remove the mouse-ball cover.
3. Turn your mouse right-side up. The ball should drop into your hand. If it doesn't, gently shake the mouse until the ball drops out of its socket.
4. Once the ball is free, use adhesive tape to pick up any dust or lint on the surface of the ball. Wipe away dirt or lint inside the mouse socket. You can also blow gently to remove dirt and lint.

If lint is trapped inside the socket or on the rollers, use a cotton swab dipped in isopropyl alcohol to loosen it. Allow surfaces to dry completely after cleaning.

5. Return the ball to its socket and replace the mouse-ball cover.

Micron 486PCI Magnum User's Guide

Mouse Settings

The following table lists the settings stored in the MOUSE.INI file, together with default and allowable values. The syntax for each setting is the name of the setting, followed by an equal sign (=), and a value for that setting. See Help in Mouse Manager for Windows for more information about MOUSE.INI settings ("The MOUSE.INI File").

The exact setting names are listed in your MOUSE.INI file.

<u>Setting</u>	<u>Default Value</u>	<u>Allowable Values</u>	<u>Switches</u>
Mouse Type	none	Serial 1,2 PS/2 InPort 1,2 Bus	/Cn /Z /In /B
Interrupt Rate	1	0,1, 2, 3, 4	/Rn
Sensitivity			
Horizontal only	50	5-100	/Hn
Vertical only	50	5-100	/Vn
Horizontal and vertical	50	5-100	/Sn
Active Acceleration Profile	2	1, 2, 3, 4	/Pn
Cursor Display			
Cursor Display Delay	0	0-10	/Nn
Force Default Cursor	off	on/off	/M
Hardware Cursor Support	off	on/off	/Y
Rotation Angle	0	0-359	/Or
Button Selection			
Primary	1	1,3	/KPnSm
Secondary	3	1,3	/KPnSm
Load Mouse in Low Memory	off	on/off	/E
Find all Mouse Devices	off	on/off	/F
Help for Mouse Switches	off	on/off	/?

Product Support

If you have a problem with your mouse, first check "Installing the Hardware" and "Installing the Software" in this section to make sure that the mouse is installed correctly.

If you cannot find the answer in this chapter, contact Micron Computer, Inc. When you call, you should be at your computer with the following information at hand:

- The FCC ID number (found on the underside of the mouse)

- The Mouse User's Guide*

- The make and model of your computer

- An MS-DOS system disk for restarting your computer

- A list of the peripheral devices attached to your computer

- The exact wording of any messages that appeared on your screen

- What happened and what you were doing when the problem occurred

- How you tried to solve the problem

United States Radio and TV Interference Regulations

The Microsoft hardware device(s) described in this manual can radiate radio frequency (RF) energy. If not installed and used in strict accordance with the instructions given in this manual, the device may cause harmful interference with radio and TV reception. Any cable that is connected to the Microsoft Mouse connector must be a shielded cable that is properly grounded.

Your Microsoft hardware device has been tested, and it complies with the limits for a Class B computing device in accordance with the specifications in Part 15 of the Federal Communications Commission (FCC) rules. These limits are designed to provide reasonable protection against harmful RF interference in a residential installation. There is, however, no guarantee that RF interference will not occur in a particular installation.

To determine if your hardware device is causing interference, disconnect the device from your computer. If the interference stops, it was probably caused by the device. If the interference continues after you disconnect the hardware device, turn the computer off and then on again. If the interference stopped when the computer was off, check to see if one of the input/output (I/O) devices or one of the computer's internal accessory boards is causing the problem. Disconnect the I/O devices one at a time and see if the interference stops.

If your computer does cause interference, try the following measures to correct it:

- Relocate the radio or TV antenna until the interference stops.

- Move the computer farther away from the radio or TV, or move it to one side or the other of the radio or TV.

- Plug the computer into a different power outlet so that the computer and radio or TV are on different circuits controlled by different circuit breakers or fuses.

- If necessary, ask your computer dealer or an experienced radio-TV technician for more suggestions. You may find helpful information in the booklet *How to Identify and Resolve Radio-TV Interference Problems*, published by the FCC. The booklet is available from the U.S. Government Printing Office, Washington, D.C. 20402. The stock number is 004-000-00345-4.

NOTE: Any changes or modifications not expressly approved by Microsoft could void the user's authority to operate this device.

Canadian Radio Interference Regulations

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Cet appareil n'émet aucune interférence radioélectrique supérieure aux limites imposées aux appareils numériques de classe B et décrites dans le règlement du Ministère des Communications du Canada concernant le brouillage radioélectrique.

Introduction

If you are experiencing problems with your Micron system and the Troubleshooting section located in Chapter 6 does not provide the information needed to correct your problem, feel free to contact Micron Technical Support at 1-800-877-8856. But before you do, take a few minutes to read this section for information about the equipment and what you might need to help the technical support representative diagnose the problem.

Before You Call

Before contacting Micron Technical Support, please follow the next few steps. They are designed to prepare you for any of the questions the technical support representative might ask or any procedures he/she may need you to do. This will help solve your problem in the fastest possible time.

- 1) Make sure your system is plugged into a grounded power outlet.
- 2) Locate the failing system as near a telephone as possible, preferably close enough so that you can simultaneously talk with the technical support representative and work on the system.
- 3) Have a medium to small sized Phillips-head screwdriver available. It's possible you may need to open your system and remove boards to help troubleshoot the problem.
- 4) Write down all error information you can remember, including error messages, software used (including version numbers), etc.

Hopefully Micron Technical Support will be able to solve your problem as quickly as possible, however in some extreme cases your system may need to be returned to Micron Computer, Inc. for repair. The next section describes what to do if this is the case.

Micron 486PCI Magnum User's Guide

Returning Equipment to Micron

If it is determined that your system needs to be returned to Micron for repair or replacement, please observe the rules listed on the next page. Failure to follow any of these rules may result in long delays in repair or the simple return of the system without repair.

- 1) Contact Micron Technical Support at 1-800-877-8856 to obtain an RMA (Return Material Authorization) number and to obtain shipping instructions before returning any portion of your system.
- 2) Make sure all printed-circuit boards or static-sensitive peripherals are completely enclosed in anti-static bags or foam.
- 3) Print the RMA number in large, black ink on the outside of the shipping boxes.
- 4) Enclose a note describing the problem as well as the name of the technical support representative who authorized the return.

Micron also highly recommends that you follow these additional steps for your protection:

- 1) Make a complete backup of your hard drive(s) before returning the system.
- 2) Use the original packing material that came with your system.

Please ship to the following address:

Micron Computer, Inc.
Attn: RMA #xxxx
915 E. Karcher Rd.
Nampa, ID 83687

Appendix B: Post and Boot Messages

Introduction

POST (Power On Self Test) has two kinds of messages; those messages are the Error message and the Informational message. The following tables list these messages, their causes, and their solutions. If you continue to experience problems and this section fails to alleviate the problem, please feel free to contact Micron technical support (see Appendix A: Contacting Technical Support).

Message	Possible Cause	Solution
Diskette Configuration Error	The configuration is not specified.	Change the configuration.
Diskette Drive Reset Failed	The diskette adapter has failed.	Check the diskette adapter.
Diskette Drive 1 Seek Failure	The B drive failed or is missing.	Check the B drive.
Diskette Drive 0 Seek Failure	The A drive failed or is missing.	Check the A drive.
Diskette Read Failure; Strike F1 To Retry Boot	The diskette is not formatted or is defective.	Replace the diskette with a formatted diskette and retry.
Display Adapter Failed; Use Alternate	The color/monochrome switch is not set correctly, or the primary video adapter failed.	Change the switch to the correct setting, or check the primary video adapter.
Errors Found; Disk X failed Initialization	The POST reports hard disk configuration information is incorrect.	Rerun SETUP and enter the correct hard disk information.
Errors found; Incorrect Configuration Information; Memory Size Mismatch	The POST reports the size of base, or the expansion memory, does not agree with configuration information.	Enter correct memory size and rerun Setup procedure.

Table B-1

Micron 486PCI Magnum User's Guide

Message	Possible Cause	Solution
Gate A20 Failure	Protected mode can not be enabled.	Check system board.
Hard Disk Configuration Error	The specified configuration is not supported.	Correct the hard disk configuration.
Hard Disk Controller Error	The controller card has failed.	Replace controller card.
Hard Read Failure Strike F1 To Boot	The hard disk failed.	Press F1 to reboot. Replace hard disk if that does not work.
FDD Controller Failure	Diskette controller failed.	Replace controller card.
FDD A Is Not Installed	Can not find diskette controller for drive A.	Install or replace controller card.
FDD B Is Not Installed	Can not find diskette controller for drive B.	Install or replace controller card.

Table B-2

Appendix C: Hard Drive Information

BIOS Hard Disk Types . . .

Type	Cylinders	Heads	Write- Precomp	Landing Zone	Sectors	Capacity (Mbytes)
1	306	4	128	305	17	10
2	615	4	300	615	17	20
3	615	6	300	615	17	31
4	940	8	512	940	17	62
5	940	6	512	940	17	47
6	615	4	65535	615	17	20
7	462	8	256	511	17	31
8	733	5	65535	733	17	30
9	900	15	65636	901	17	112
10	820	3	65535	820	17	20
11	855	5	65535	855	17	35
12	855	7	65535	855	17	50
13	306	8	128	319	17	20
14	733	7	65535	733	17	43
15	Unused	0	0	0	0	0
16	612	4	0000	663	17	20
17	977	5	300	977	17	41
18	977	7	65535	977	17	57
19	1024	7	512	1023	17	60
20	733	5	300	732	17	30
21	733	7	300	732	17	43
22	733	5	300	733	17	30
23	306	4	0000	336	17	10

Continue to B-2 for additional types

Micron 486PCI Magnum User's Guide

Type	Cylinders	Heads	Write- Precomp	Landing Zone	Sectors	Capacity (Mbytes)
24	325	7	0000	925	17	54
25	615	9	65535	925	17	69
26	754	7	754	754	17	44
27	754	11	65535	754	17	69
28	699	7	256	699	17	41
29	823	10	65535	823	17	68
30	918	7	918	918	17	53
31	1024	11	65535	1024	17	94
32	1024	15	65535	1024	17	128
33	1024	5	1024	1024	17	43
34	612	2	128	612	17	10
35	1024	9	65535	1024	17	77
36	1024	8	512	1024	17	68
37	615	8	128	615	17	41
38	987	3	987	987	17	25
39	987	7	987	987	17	57
40	820	6	820	820	17	41
41	977	5	977	977	17	41
42	981	5	981	981	17	41
43	830	7	512	830	17	48
44	830	10	65535	830	17	69
45	917	15	65535	918	17	114
46	1224	15	65535	1223	17	152
47	User Configured					

The Micron Supplied Hard Drives . . .

Most Micron computers come with preconfigured Maxtor, Quantum, or Connor hard drives installed. Micron uses several different models, depending on the customer's order. The IDE drives all have integrated IDE controllers with a 1:1 interleave rating. All drives have been low-level formatted and tested at the factory. ***Never low-level format any of these drives as this may cause the drive to fail.*** The drive statistics are shown on this and the following page. Make a note of them in case your internal battery fails or the CMOS loses its information.

Model	Cylinders	Heads	WPcom	Lzone	Sectors/Tracks	Setup Size
Maxtor:						
7080A	981	10	65535	0	17	81MB
7120A	936	16	65535	0	17	124MB
or	1024	16	65535	0	17	119MB
7213A	683	16	65535	0	38	203MB
LXT213A	683	16	65535	0	38	203MB
7245A	967	16	65535	0	31	234MB
LXT340A	654	16	65535	0	63	322MB
7345A	790	15	65535	0	57	324Mb
LXT535	1036	16	65535	0	63	522MB
MXT540AL	1024	16	65535	0	63	540MB

Appendix C: Hard Drive Information

Model	Cylinders	Heads	WPcom	Lzone	Sectors/Tracks	Setup Size
Quantum:						
52AT LPS	751	8	65535	0	17	50MB
80AT	1024	9	65535	0	17	77MB
120AT	814	9	65535	0	32	114MB
210AT	873	13	65535	0	36	199Mb
245AT	723	13	65535	0	51	234MB
Conner:						
CP30084E	903	4	65535	0	46	85MB
CP30104	776	8	65535	0	33	120MB
CP30174E	903	8	65535	0	46	170MB
CP3204	683	16	65535	0	38	200MB
CFS210A	685	16	65535	0	38	209MB
CP30254	895	10	65535	0	55	252MB
CP30344	665	16	65535	0	63	343MB
CFS420A	826	16	65535	0	63	425MB
CFA540A	1023	16	65535	0	63	545MB
CP30544	1023	16	65535	0	63	545MB

How the Setup Size is Calculated . . .

Quite often the CMOS setup program reports a hard drive size that is smaller than the hard drive actually installed. This is not a mistake. The hard drive size is determined in the following fashion:

$$\frac{\text{Cylinders} \times \text{Heads} \times \text{Sectors} \times 512 \text{ (bytes per sector)}}{1,048,576 \text{ (actual size of a MB in bytes)}}$$

For example, we will calculate the size of the Maxtor 7245A:

$$967 \times 16 \times 31 \times 512 = 245,571,584 \text{ bytes}$$

$$\frac{245,571,584}{1,048,576} = 234.195 = 234\text{MB}$$

By this example, although the Maxtor 7245A is shown as a 234MB drive, it actually possesses over 245.4 million bytes of storage space.

C

C

C

Glossary

Application: A software program that operates under an operating system to perform a specific task.

BIOS: Basic Input/Output System. Programs that are permanently stored in the system board's ROM chips providing functions such as the power-on self test. Also see ROM.

Boot: To start the computer system and load the operating system.

Bus: The set of address or data lines used to transfer information between different components within a computer (such as memory, the microprocessor, and the expansion slots).

Cache: Provides fast, local storage for frequently accessed instructions and data to provide the processor with the fastest stream of information possible. Even so, main memory is kept current.

Clock: A circuit that sends a consistent, periodic signal that is used to synchronize the computer and to step information through the system.

Closed: A circuit that is complete. Usually accomplished by placing a jumper over two pins on the system board or a peripheral card. Also see "Open" and "Jumper."

CMOS: Complementary Metal Oxide Semiconductor. A logic circuit family that uses very little power. Sometimes used to store information by applying constant, uninterrupted power through the use of an external battery.

Coprocessor: A microprocessor device that performs specialized computations (such as floating-point arithmetic) much more efficiently than the microprocessor alone.

CPU: Central Processing Unit. The integrated circuit chip that performs the actual computing functions of the computer. Other chips perform support functions like storing data and controlling peripherals. Also see microprocessor.

Disk: See "Floppy Disk" and "Hard Disk."

DMA: Direct Memory Access. A method for transferring data directly to and from system memory, bypassing the microprocessor.

DOS: See "Operating System."

DRAM: Dynamic Random Access Memory; requires a periodic refresh cycle to keep the stored information from being lost. Loss of power causes loss of data in this memory.

EISA: Acronym for Extended Industry Standard Architecture.

Micron 486PCI Magnum User's Guide

Energy Star: A program developed by the EPA to promote the use of more efficient computers.

Expansion Slot: A connector on the motherboard for holding a peripheral card.

Floppy Disk: A 3.5 inch or 5.25 inch removable storage medium used for storing programs and files externally from the computer system.

Format: A process which prepares a disk to hold data. For hard disks, there are two formatting process: low-level and high-level.

Green: Definition used to describe a device that adheres to the EPAs Energy Star program.

Hard Disk: An internal or external, high capacity, high speed storage medium.

Hertz (Hz): A unit of frequency equal to one cycle per second.

I/O Port: A connector that allows external and some internal peripherals to communicate with the computer system (e.g., serial ports and parallel ports).

I/O: An abbreviation for "input/output," a generic term that refers to the devices and processes involved in the computer's reading and writing data.

Integrated Circuit: An electronic device that combines thousands of transistors on a small chip of silicon or other semiconductor. Such devices are the building blocks of computers.

Interface: The connection between the computer and its human operator, or between the computer and a peripheral device.

ISA: Industry Standard Architecture. The standard bus interface that was implemented in the IBM AT.

Jumper: On a printed circuit board, a patch cable or wire used to establish a circuit.

Megahertz (MHz): A frequency of 1 million cycles per second.

Memory: Devices used to hold information and programs while they are being accessed by the microprocessor. See also RAM and ROM.

Microprocessor: An integrated circuit that contains the circuits the computer needs to calculate and to communicate with the other parts of the system. See also CPU.

Modem: A device designed to allow computers to communicate over standard phone lines.

Motherboard: See "System Board."

Appendix D: Glossary

- Non-Volatile Memory:** Memory which is maintained even when power is not on.
- Open:** A circuit that is not complete. Usually accomplished by removing a jumper from two pins on the system board or a peripheral card. Also see "Closed" and "Jumper."
- Operating System:** The software that provides a link between application programs and the computer hardware (e.g., disks, memory).
- Page Mode:** Special function in DRAM that saves up to about 30% in cycle time by not re-loading RAS bits.
- Page:** Sections of memory consisting of sets of consecutive bytes. Pages begin on 4-Kbyte boundaries.
- PCI:** Peripheral Component Interconnect. This is a type of bus architecture providing superior throughput and compatibility.
- Pentium:** A microprocessor providing such features as 16KB of internal cache and a 64 bit data/address path. Sometimes referred to as a 586.
- Peripheral Card:** A printed circuit board that gives the computer added capability, such as more memory or control of a new device. A card plugs into one of the expansion slots located on the system board.
- Peripheral:** Any device that is connected to the computer system (e.g., printers, keyboard, plotters, etc.).
- Pin:** Any of the leads on a device, such as an integrated circuit, that plug into a socket and connect to a system.
- Power-On Self Test (POST):** Check-out procedures that the BIOS runs automatically when the system is turned on. These procedures verify that all computer hardware is functioning properly. If the test detects problems, the computer displays error codes before (or instead of) starting the operating system. The error codes can help a service person determine what is wrong with the computer.
- Program:** A set of instructions that a computer interprets to perform some task. Also see "Application" and "Operating System."
- RAM:** Random-Access Memory. The type of computer memory that can be used to store information while a program is running. RAM consists of a number of small integrated circuits that are plugged into the motherboard or an external memory card.
- ROM:** Read-Only Memory. The type of computer memory that is used to permanently store the information vital to computer operation, including some parts of the operating system. ROM is permanent and the contents will not be lost when the computer is turned off.
- Setup Program:** Used to inform the computer about installed peripheral, memory, configuration information, date and time, etc.

Micron 486PCI Magnum User's Guide

Shadow RAM: A method of copying BIOS routines from slower ROM chips to much faster RAM, increasing system performance.

SIMM: Single In-line Memory Module: A small circuit board containing memory components that plugs into special sockets located on the motherboard for upgrading the system memory. These modules generally need to be inserted in groups of two or four.

Software: A general term that describes a program or set of programs.

SRAM: Static Random Access Memory. Does not require periodic refreshing that dynamic memory requires.

System Board: The large printed-circuit board in a computer on which most electronic devices are mounted; the primary board in a computer. All other interfaces receive control signals or information from the systemboard. Also commonly referred to as the "mainboard" or "motherboard."

System Unit: The description for the computer case and all internal components (e.g., the system board, expansion cards, disk drives, power supply, etc.).

System: The assembly of basic components (e.g., power supply, motherboard, memory, video monitor, etc.) united by some form of communication to form an organized whole.

VESA: Acronym for Video Electronics Standard Association.

Wait State: A delay in the computer's information processing cycle caused by a difference in speed between a faster processor and slower memory. A 0 wait state means the processor does not have to "wait" for memory, and can access data as fast as needed.

Write Precompensation: In a hard disk, the varying of the timing of the read/write head current on the inner tracks of the disk to maintain a constant signal.

Warranty Information

Micron Computer, Inc. warrants your new Micron PowerServer computer to be in good working order and free from defects in materials and workmanship for one year from the date of purchase. This warranty only covers defects arising under normal use and does not include malfunctions or failures resulting from misuse, abuse, neglect, alteration, modification, improper installation, or repairs by anyone other than Micron Computer, Inc.

Repair or replacement of defective parts or refund of the price shall be the only remedies available to the purchaser. Micron Computer, Inc. may, in lieu of refund and at its option, repair or replace the customer's system or any of its individual components with new or reconditioned parts, and any replaced systems or components become Micron's property.

Micron Computer, Inc. shall not be liable for incidental or consequential damages for breach of any expressed or implied warranty related to the product, except to the extent prohibited by applicable law. In no event shall Micron be liable for indirect, special, or consequential damages such as loss of profits or business opportunities. Micron makes no warranty of merchantability of fitness for a particular purpose in relation to this product.

Some states do not allow the exclusion or limitation of implied warranties of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to a particular case. This warranty gives the customer specific legal rights and the customer may also have other rights which vary from state to state.

Micron Computer, Inc. products are not authorized for use as critical components in life support devices of systems without the express written consent of the President of Micron Computer, Inc.

©Copyright 1993
All Rights Reserved

Micron Computer, Inc.
915 Karcher Road
Nampa, Idaho 83687 USA
(208) 465-3434 (voice)
(208) 465-3424 (fax)
(800) 877-8856 (technical service)

The Information in this manual has been carefully checked and is believed to be accurate. However, Micron Computer, Inc. assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Micron Computer, Inc. be liable for direct, or omission in this manual, even if advised of the possibility of such damages.

Micron Computer, Inc. reserves the right to make changes to this manual and the products it describes at any time, without notice or obligation.

Micron Computer, Inc.

FCC Information

Class B Digital Device: This device complies with Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio of television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the part responsible for compliance could void the user's authority to operate the equipment.

(C) Copyright 1993
All Rights Reserved

Micron Computer, Inc.
915 Karcher Road
Nampa, Idaho 83687 USA
(208) 465-3434 (voice)
(208) 465-3424 (FAX)
(800) 877-8856 (service)

The Information in this manual has been carefully checked and is believed to be accurate. However, Micron Computer, Inc. assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Micron Computer, Inc. be liable for direct, or omission in this manual, even if advised of the possibility of such damages.

Micron Computer, Inc. reserves the right to make changes to this manual and the products it describes at any time, without notice or obligation.

Trademarks

Intel is a registered trademark of Intel Corporation.

All other trademarks, registered and unregistered, are property of their respective holders.

Micron Computer, Inc.
486 PCI User's Guide
Revision 1.0 2/94
P/N MA1062
PRP

Micron Computer, Inc.

Notes

Notes

Notes
